

**PRESS POWER BUTTON FOR
3 SECONDS TO TURN ON / OFF.**



L	-----		-----	140°C 284°F
M	-----		-----	160°C 320°F
H	-----		-----	190°C 374°F

Automatic shut off after ten minutes
if you're not using it


Instructions

1. Press power button for 3 seconds to turn on the machine, there are 3 temperature modes for your choice: Green light means mode 1, Blue light means mode 2, Red light means mode 3. When the light is flicking, which means it's heating up; when the light stays on, it has reached to desired temp.
2. Every time you want to change mode, just need to press the power button for 3 seconds.
3. Choose the temperature mode you need, wait the light stays on, then you can start to heat transfer;
4. The mini heat press machine will automatically shut down if non-use for **10** minutes;

Warranty

One-year warranty. The warranty service can be used only when the product fails during normal use. It does not cover damage caused by accident, abuse, misuse, water, fire or other natural disasters or due to improper use.

AIDARY Mini Heat Press User Manual



Specification:

Power: 200W

Voltage: 110V/220V

Product Weight: 1.21Lbs

Package Weight: 1.58Lbs

Product Size: 6.7"x3.4"x4.2"

Package Size: 9.6"x7.2"x4.8"